



Banat 1




BANAT 1		D25
IMP pumps:		
CL 50-1-4	CL 401	
CL 803-4	CL 502	
CL 652-4	CL 503	
CL 801		

Banat 2




BANAT 2		D25
IMP pumps:		
CT 503	CTLA 503	
CT 653	CTLA 653	
CT 653-48		

Banat 3




BANAT 3		D28
IMP pumps:		
L 802-4	CL 1002	
CL 402	CTL 802	
CL 651	CTL 803	
CL 653	CLP 401	
CL 501		

Banat 4




BANAT 4		D30
IMP pumps:		
CL 40-1	CT 502	
CL 501	CT 803-4	
CL 502L	CTL 501	
CL 1001	CTLA 501	
CT 501	CTLA 50-2	

Banat 5



BANAT 5		D33
IMP pumps:		
CLP 501		
CLP 801		

Banat 6



BANAT 6		D32
IMP pumps:		
CT 651-4	CT 1002-4	
CT 801-4	CTLA 502	
CT 802-4	CTLA 1002	
CT 1001-4		